

Installation Instructions for the 15" Shelf

Tools and Materials Required:

- Torpedo Level
- Caulk Gun
- Hot Glue Gun
- Silicone 100% (to be used with Caulk Gun)
- Hot melt glue (to be used with Hot Glue Gun)
- Denatured Alcohol
- Pencil/Marker



1. Use denatured alcohol to clean the surface of the wall and the desired placement of the shelf. DO NOT clean this product with any abrasive material or cleanser. (i.e., steel wool, Comet, Ajax, Soft Scrub, etc.). These abrasives will dull the lustrous finish.

2. Using a leveler, draw a short line to mark where the shelf will be installed.

3. Starting in the center of the holes, measure and mark the distance between the 2 holes located in the back of the shelf.

4. Drill 2 holes into the wall and install 2 anchors. Then, screw 2 wide head screws into the wall. These screws will be inserted into the 2 back holes of the 15" shelf.

5. Prepare a hot glue gun, and a caulking gun with 100% silicone.

6. With the caulking gun filled with 100% silicone, squeeze the silicone into the 2 holes of the shelf until it slightly overflows in order to assure it will touch the wall when the shelf is pushed against the wall.

7. Apply silicone around the perimeter of the back side of the shelf. Be mindful of the amount used in order to ensure the silicone will not spread beyond the edges on the wall.

8. In order to attach the shelf to the wall instantly, apply a line of hot glue across the middle section of the shelf. Only use enough to ensure the shelf will stick to the wall, and be sure to avoid the 2 holes.

9. Attach the adhesive side of the shelf to the wall.

10. Once the shelf is placed on the wall, finish applying silicone around the edges of the shelf. Using denatured alcohol, clean off any excess silicone around the edges of the shelf and wall.

11. For precautionary purposes, apply masking tape over the shelf and attach it to the walls to hold it in place.

