



CAREGIVER SHOWER CURTAIN INSTALLATION GUIDE



Before You Begin

EVALUATE THE WALL BEFORE STARTING INSTALLATION

- Evaluate the wall surface and desired mounting location to determine what type of wall fasteners are required to properly secure the caregiver rod mounting bracket. Screws and wall anchors are included with the kit.

Installation Tip:

Drill a small test hole. For ceramic tile, drill in grout line if possible.

- Check the desired wall location for any potential obstructions and/or uneven surfaces that would prevent the bracket from mounting flush to the wall surface.

BRACKET INSTALLATION:



CHECK LIST OF TOOLS REQUIRED

- Tape measure
- Clear 100% Silicone caulk
- Portable drill with countersink bit
- Marker
- Philips screwdriver



Step 1: Determine height

Measure and determine desired height and location mounting location wall support. **NOTE:** the curtain must touch floor when installed in barrier free showers.



Step 2: Mark drill locations



Step 3: Drill holes.

Determine correct size drill bit for the fastener to be used. Always use a drill bit with countersink head to avoid risk of screw cracking or chipping finish (Tile, marble, granite, acrylic or Fiberglass, other).



Step 4: Apply Caulk.

Always apply caulk in a circular pattern around each hole drilled to prevent water migration into the wall cavity. Use a premium clear silicone adhesive caulk.



Step 5: Tighten Screws equally.

Tighten each screw in an alternating sequence pattern until bracket is firmly pressed to the wall without movement. This will limit risk of cracking wall surface.



Step 6: Install rod.

Insert the J shaped end of the rod into the female slot of the wall bracket.



Step 7: Extend rod.

To extend the telescopic rod across the full width of the shower opening, grip and twist cap by hand and pull to extend rod across shower opening. The extension section of rod will be tight for shipping reasons, use of pliers may be required.



Step 8: Install Receiver bracket.

Place receiver bracket in position beneath the location where the rod touches the wall. Repeat steps 1-5.



Step 9: Install curtain.

Thread top of curtain through telescoping rod to complete the installation.

Discover more products
and additional information at
www.ellasbubbles.com

Toll Free: 800-480-6850
Office Direct: 312-666-3552

