

## Warranty Activation Form

1 of 2

## **INSTALLER'S INFORMATION** Page 1 Name Address City State Zip Telephone Email Date Signature Upon completing the installation of an Ella Walk In Bath, the following Warranty Activation Form must be completed, signed by both the customer and installer, and returned to Ella's Bubbles, LLC. In order for the Warranty to be activated (faxed, scanned, or emailed, or hard copy mailed). To be initialed by the installer(s) Tub is level in all directions and all support legs are touching the ground. \_Tub is installed by a licensed electrician. Tub must be installed on a dedicated GFCI circuit breaker. Frame of the tub has been properly grounded. \_Door Seal has been cleaned with rubbing alcohol to remove any dust or debris left over from construction. \_Temperature Control Valve operated on both hot and cold settings. \_\_Both diverters function properly. \_\_Hand Shower functions on all settings without leaking. \_All supply lines have been checked for leaks while both diverters are on. Drains open and close properly, and the locking nut has been tightened on both stoppers. Door seal is water tight after tub has been filled for a minimum of 20 minutes. After running for a minimum of 20 Minutes both the Hydro and Air Pumps are functioning properly and all\_ connections to the pumps and jets are water tight. Chromatherapy Light and the Ozone Sterilization are working properly. (When the Ozone is on by itself it will make a light humming noise). \_All drain fittings have been checked for leaks while the tub is draining. Unit is installed with access to both plumbing and electrical connections.

Must submit electrician's license and insurance information with warranty.



## Warranty Activation Form

2 of 2

OWNER'S INFORMATION

Name			
Address	City	State	Zip
Telephone	Email		
Date	Signature		
Model:	Serial Number:		
Purchase Date:	Purchase Price:		
Place of Purchase:			
Contact Name:	Phone Number:		

## Copy of sales receipt must be included with warranty activation forms.

To activate manufacturer's warranty, please complete both pages and use one of the options below to submit.

Via mail: Ella's Bubbles, LLC.

Warranty Department

2101 S. Carpenter St., Chicago, IL 60608

Via fax: 1-312-666-3551

Via email: warranty@ellasbubbles.com